GUIDE

Powder Coating With ZRC



IMPORTANT: ZRC MUST BE APPLIED TO CLEAN, DRY, BARE METAL SURFACES!

- Apply the ZRC and GALVILITE coating to the clean, bare, dry metal surface.
- Bake the ZRC at the same temperature, and for the same amount of time as you would the powder coating. This prevents pinholes from forming as a result of solvent evaporation which occurs as the product cures.
- 3 Allow the ZRC to cool to room temperature.
- After allowing ZRC to cure at least 12 hours at room temperature, apply the powder coating and follow the specified powder coating procedure for applying and heating etc.



Please call our toll-free number 1-800-831-3275 to speak with a technical representative or <u>visit our store</u> to place an order



STOP RUST AND RUST CREEPAGE

GALVANIZING

COMPOUNT FOR IRON AND